

TO START THE SYSTEM AND POWER ON PROJECTOR


- Slide the touchscreen on the wall to start up the system.

The projector will turn on and screen will come down automatically.




SELECT A SOURCE

- LOGO is the default.
- Press South, West, or East Laptop depending on the label on the wall you are connected to.
- Plug Laptop into the USB-C or HDMI cable as needed.



AUDIO CONTROLS

- Press red Audio Controls Button
- Adjust volume sliders
- Bright red box is muted
- Black box is unmuted
- Computer Volume can be controlled from the homepage
- To adjust wireless mics, click the wireless mic controls



TO SHUT DOWN

- Press the red Power button
- Press "Shutdown System"

